

For a better understanding of this product, please read this user manual thoroughly before using it.

USER'S MANUAL

GSM Alarm System

CONTENTS Function Introduction -Alarm Host Diagram -Functions Settings . Initialization \_ \_ \_ . Enter Settings - -Exit Settings - - . Factory Reset - -Coding of Remote Controller -Delete Remote Controller - - -Coding of Defense Zone - -Delete Defense Zone - -Change Password ---Change Operation Password - - -Change Program Password - - -Clock Setting - - -Timing Settings - - -Timely Arm---Timely Disarm - -Timing Control - - -Out Arm Delay Setting -Alarm Delay Setting - -Alarm Number Setting - - -Delete Phone Number----

CONTENTS SMS Number Setting-----Delete SMS Number - - - - -SMS Notification for Arm/Disarm - -Defense Zone Programming----Home Arm Defense Zone Setting- -Voice Recording - - - - -Siren Setting - - - -Operation Instructions. System Status - - - -Remote Controller Operate - . Answer Alarm Call---Remote Control-------- 17-18 Emergency Help----System Dialing Function - ----- 18-18 Alarming Record Checking---- 18-19 GSM Signal Checking ----- 19-19 -- 20-20 Technical Parameters - ----- 21-21 Components List - - ----- 22-22 Care and Maintenance - -

Alarm Host Diagram Alarm Panel front schematic diagram: Alarm Panel back schematic diagram: Battery Slot Wired terminal block: LB+ LB- 12V GND Z1 Z2 Z3 Z4 Z5 Z6 Siren Port 12V Output Port (Positive) (Positive)
Siren Port (Negative)

Alarm Host Diagram Positive of two-way speaker (red cable) Negative of two-way speaker (black cable) 12V Output Port (Positive) 4 GND Ground Wired sensor 1: support both NO and NC Wired sensor 2: support both NO and NC Wired sensor 3: support both NO and NC Wired sensor 4: support both NO and NC 8 Zone 4 Wired sensor 5: support both NO and NC 9 Zone 5 Wired sensor 6: support both NO and NC Put SIM card in this card slot Plug in siren connector Connect to the external power supply Switch for backup battery. Turn it on after 1. "LB -" and "LB +" are to connect external speaker. If you think the internal speaker is not loud enough, please contact us for 2. Connect one cable of the wired sensor to GND and the other to

Alarm Host Diagram Alarm Status Indicator Fire Alarm Gas Leakage Window Alarm Door<sup>-</sup>Alarm SOS Hall Alarm Balcony Alarm Boundary Alarm [ Functions Settings ] Please insert SIM card and plug in power adaptor, and then power on the system, all the LED lights will be on for 2 seconds and you will hear a long beep; the system comes into initialization. After the time clock displays on the LCD screen, the [GSM] starts flashing and the main unit starts to detect the GSM network until a long beep. Finally, turn on the backup battery switch.

Then the [GSM] indicator goes out indicating the system comes into disarm 2. Enter Settings In the state of disarm, input 4-digit password by the keypad on the main unit and press [#] button to confirm. You will hear a voice prompt: please enter instruction. At the same time, [SET] indicator is on without flashing and [0000] displays on the screen, indicating the system enters setting status. You can perform different settings repeatedly as long as the system keeps in setting status. The system will exit setting mode and return to disarm status Operating method:  $[20] \Rightarrow [A] \Rightarrow [\#]$ if you don't press any keypad button for 40 seconds. A indicates:  $1\sim8$  remote controllers number.

**Functions Settings** 

For example: setup 13822222222 as the first SMS receiving number

In setup state, use keypad to input [57] ~ [59], a nd then press [#] button

to confirm. The main unit will make a beep, the [ Signal ] indicator will

flicker once and you will hear "delete completed", which indicate SMS

XX indicates: address codes of message-receiving numbers from the first

After starting this function, the system can send SMS to three SMS receiving

numbers (57~59 as mentioned above) when the system enters arm/ disarm

status through wireless remote controllers or its panel keyboard operation.

For example: delete the first SMS user number from the system

In setup state, input the command **77 + [1/0]** + # (1: ON, 0: OFF)

1). SMS Notification for Arm/Disarm (Default: OFF)

Operating method: [**57**]⇒[138222222]⇒[**#**]

15. Delete SMS Receiving Number

number is deleted successfully.

group to the third group [**57**] ~ [**59**]

16. Defense Zone Programming

Back-up Battery

Remote control Password 1234

Siren sound time

Siren Volume

Operating method: [**XX**]⇔[#]

Operating method: [**57**]⇔[#]

The system default password is [8888]. Operating method: [ XXXX ] ⇒ [#] X indicates the new 4-digit password. 3. Exit Settings Press [\*] and [\*] buttons, the main unit emits a long beep and exits settings. The [ **SET** ] indicator goes out and the system returns to disarm state. Operating method: 【★】 ⇒【#】 4. Factory Reset In disarm status, use keypad to input [95175308246] and press [#] to confirm, all the LED indicators will be on for 2 seconds and you will hear a long beep. The main unit gets all its settings cleared and restores to its factory settings Operating method: [**95175308246**] + [#] 5. Coding of Remote Controller The remote controller has to be code to the alarm host in order to perform In setup state, use keypad to input [20], input the remote controller number [1~8], and then press [ # ] to confirm. The main unit emits a long beep and you will hear " remote control coding " . The [ $lackbreak{lack}{lack}$ ] indicator is on without flashing; press any button on the wireless remote controller, the main unit makes a long beep and you will hear "coding completed" ,  $\left[lackbreak{lackbreak{\delta}}{lackbreak{\delta}}\right]$  indicator goes out, indicating the remote controller succeeds in coding.

**Note**: In setting status, press can delete the numbers input.

Functions Settings

Functions Settings

Components list

Functions Settings You can add maximum 8 remote controllers. 6. Delete Remote Controller The remote controller can't control the main unit after it's deleted. In setup state, use keypad to input [21], then input the remote controller number [1-8], and then press [#] to confirm. The main unit emits a long "delete completed" .

beep and the [Signal] indicator flickers once. You will hear a voice prompt Operating method:  $[21] \Rightarrow [A] \Rightarrow [\#]$ A indicates: 1~8 remote controllers number. 7. Coding of Defense Zone Wireless detectors have to be coded to the main unit in order to trigger

In setup state, use keypad to input [23], input the defense zone number you want to code [ **01~99** ], and then input [#] to confirm. The main unit emits a long beep and the corresponding defense zone is displayed on the screen. You will hear a voice prompt "detector coding". Then trigger a wireless detector to emit a wireless signal; after receiving the signal, the main unit makes a long beep, and you will hear "coding 

Operating method: [**23**]⇔[**XX**]⇔[#] XX indicates: 01 ~99 defense zones number Functions Settings

8. Delete Defense Zone The wireless detector can't control the main unit after it's deleted. In setup state, use keypad to input [24], then input the defense zone number you want to delete [ 01~99 ], and then input [#] to confirm. The main unit emits a long beep and the defense zone indicator

Operation password is the password used to disarm or remote control.

In setup status, use keypad to input [30], then input the 4-digit new

password, and then press [#] to confirm. The main unit will make a long

Program password is the password you should input in order to setup

In setup status, use keypad to input [ 31 ], then input the 4-digit new

beep and you will hear a voice prompt "setting completed".

password, and then press [#] to confirm. The main unit will make a long

beep and you will hear a voice prompt "setting completed"

You will hear a voice prompt "delete completed"

XX indicates: 01 ~99 defense zones number

Operating method: [**24**] ⇒ [**XX**] ⇒ [#]

9. Change Password

1). Change Operation Password

Operating method:  $[30] \Rightarrow [XXXX] \Rightarrow [\#]$ 

Operating method: [30]  $\Rightarrow$  [1012]  $\Rightarrow$  [#]

2). Change Program Password

**XXXX** indicates: the new 4-digit password

For example: change the system password to 1012

Note: the operation password and the programming password can not

be set as the same number.

Operating method:  $[31] \Rightarrow [XXXX] \Rightarrow [#]$ 

Operating method: [**31**] ⇒ [**2846**] ⇒ [#]

XXXX indicates: the new 4-digit password

For example: change the system password to 2846

10. Clock Setting In setup status, use keypad to input [32], then input the last 2 digits [AA] of the present year, the two digits [**BB**] of the month, the two digits [**CC**] of the date, the two digits [**DD**] of the hour (24-hour system), the two digits [EE] of the minute, the two digits [FF] of the second, and finally enter [#] to confirm. You will hear a long beep and a voice prompt "setting completed" . Operating method: [32]⇔[AA]⇔[BB]⇔[CC]⇔[DD]⇔[EE]⇔[FF]⇔[#] AA indicates: the last 2 digits of the present year

**Functions Settings** 

BB indicates: the 2 digits of the present month CC indicates: the 2 digits of the present date DD indicates: the 2 digits of the present hour EE indicates: the 2 digits of the present minute FF indicates: the 2 digits of the present second For example: set the time as 15:35:40, Oct. 1st, 2009 Operating method:  $[32] \Rightarrow [09] \Rightarrow [10] \Rightarrow [01] \Rightarrow [15] \Rightarrow [35] \Rightarrow [40] \Rightarrow [\#]$  **Functions Settings** 

**Function Introduction** 

[Function Instruction]

☆ 7 wired and 99 wireless defense zones;

☆ LCD screen with time clock display;

3 groups of timely arm and disarm;

☆ Can store 6 phone numbers: when alarming, system will make alarm call

☆ Can store 3 SMS numbers: when alarming, system will send alarming SMS

Users can make calls by using keypad on alarm panel, just like a telephone;

☆ SOS, fire, gas, door, hall, window, balcony, and boundary places alarm;

Real-time, delay, 24 hours, bypass defense zones programming function;

Built-in AAA NI-HI rechargeable battery: make alarm when power off.

In order to make the main unit get the wireless signal well for all wireless

accessories, please put the alarm host at the central place of your defense

Make sure it's away from large metal objects and house hold appliances

which may cause high frequency interference, as well as barriers such as

One-key-control function: Out Arm, Home Arm, Remote Arm;

Wireless coding: easy to add additional wireless accessories;

Remote control Arm, Disarm, Monitor, and Intercom by phone;

Voice prompt for all operations;

to these numbers automatically;

10-second automatic message recording;

☆ Arm/ disarm by SMS or call remotely;

SMS alert for power failure or recovery;

reinforced concrete wall or fire door, etc.

[Alarm Host Diagram]

Built-in artificial intelligent English message;

Built-in artificial intelligent digital voice announcer;

11. Timing Settings 1). Timely Arm In setup status, use keypad to input [33~35], then input the hour [AA] and minute [BB] of the time you want to set to arm, and finally input [#] to confirm. You will hear a long beep and a voice prompt "setting completed". Operating method: [**XX**]⇒[AA]⇒[BB]⇒[#] **XX** indicates: the address code 33, 34, 35 of the timely arming **AA** indicates: the hour of the setting time **BB** indicates: the minute of the setting time

2). Timely Disarm In setup status, use keypad to input [36~38], then input the hour [AA] and minute [BB] of the time you want to set to disarm, and finally input [#] to confirm. You will hear a long beep and a voice prompt

For example: set the arm time as 45' 10pm

Operating method: [**33**] ⇒[**22**] ⇒[**45**] ⇒[**#**]

"setting completed" . Operating method: [XX]⇔[AA]⇔[BB]⇔[#] XX indicates: the address code 36, 37, 38 of the timely disarming AA indicates: the hour of the setting time BB indicates: the minute of the setting time For example: set the arm time as 55′ 7am Operating method: [**33**] ⇒[**22**] ⇒[**45**] ⇒[#]

**Functions Settings** 

Timing Control In setup status, use keypad to input [39], then input the number indicating turning on timely arm/ disarm [**1/0**], and then input [#] to confirm. You will hear a long beep and a voice prompt "setting completed" . The factory Operating method: [**39**]⇒[**0/1**]⇒[#] 0: turn off the function of timely arm/ disarm

For example: turn on the function of timely arm/ disarm Operating method: [**39**]⇒[**1**]⇔[**#**] Time Setting for Out Arm Delay (Default: 60 sec) In setup state, input the command: 44 + [XX] + # XX indicates: the delay time of out arm; XX= 01-99: 1 sec to 99 sec Note: The setting is effective only with the keypad operation.

The operation by remote controller or SMS is immediate arm without delay.

1: turn on the function of timely arm/ disarm

Time Setting for Alarm Delay (Default: 40 sec) In setup state, input the command: 45 + [XX] + # XX indicates: the delay time of alarm; XX= 01-99: 1 sec to 99 sec Note: The setting is effective only when a zone is set as Alarm Delay Zone. Note: Before the system enters arm or alarm status

it will emit a "Di" sound per second. 12. Alarm Number Setting In setup state, input [ 51] ~ [ 56 ], then input the voice alarm-receiving number (mobile number or telephone number), and then press [#] to confirm. The main unit will make a long beep, the [Signal] indicator will flicker once, and you will hear "setting completed", which indicate voice alarm-receiving number is set successfully. Operating method: [**XX**]⇒[**YY...YY**]⇔[**#**]

**Functions Settings** 

**XX** indicates: the 1- 6 alarming user number [**51**] ~ [**56**] YY....YY indicates: voice alarm-receiving phone number For example: set 13811111111 as the first voice call number Operating method: [51] ⇒ [13811111111] ⇒ [#]

"Z1/Z2/Z3.../Z6" .

13. Delete Phone Number In setup state, input [51] ~ [56], and then press [#] to confirm, the main unit will make a long beep and the [Signal] indicator will flicker once and you will hear "delete completed", which indicate the alarming user number is deleted successfully. Operating method: [**XX**]⇒[#] XX indicates: the 1- 6 alarming user number [51] ~ [56]

For example: Delete the third alarming user number from the system. Operating method: [**53**]⇒[**#**] 14. SMS Receiving Number Setting SMS Receiving number means when system is alarming, it will only send SMS to this mobile number. You can set maximum 3 SMS numbers.

off the siren when system alarms, you can do it by defense zone In setup state, input [57] ~ [59], then input the SMS receiving number, and then press [#] button to confirm. The main unit will make a beep, the In setup state, first input [60], then the defense zone number [01~99], then input defense zone type [1~4], then input defense zone location [Signal] indicator will flicker once and you will hear "setting completed" number [1~8], and then select siren on/off [0/1], at last press [#] to which indicate setup successfully. confirm. You will Operating method: [XX]⇒[YY...YY]⇒[#] hear the main unit emit a long beep and a voice prompt XX indicates: address codes of message-receiving numbers from the first group to the third group [**57**] ~ [**59**] Operating method:  $[60] \Rightarrow [AA] \Rightarrow [B] \Rightarrow [C] \Rightarrow [D] \Rightarrow [#]$ YY...YY indicates: the SMS receiving number

If you want to change the alarm attribute of defense zone, such as turn For example: set defense zone 12 as Home arm but not alarm Operating method: [**61**]⇔[**12**]⇒[**0**]⇒[**#**]

**AA**: defense zone number [**01~99**] means zone 1 to zone 99; **B:** defense zone type [1]: real-time defense zone [2]: 40 seconds delay defense zone [3]: 24 hours defense zone [4]: bypass defense zone C: defense zone location [1] SOS Alarm [2] Fire Alarm [3] Gas Leak Alarm [4] Door Alarm [5] Hall Alarm [6] Window Alarm [7] Balcony Alarm [8] Boundary Alarm D: siren ON/OFF: [0] OFF, [1] ON For example: set defense zone 12 to be 24-hour, fire alarm and siren on Operating method: [**60**]⇔[**12**]⇔[**3**]⇔[**2**]⇔[**1**]⇔[**#**] 17. Home Arm Defense Zone Setting If you want some detectors work and some do not, you can use [**Home Arm**] function. In setup state, use keypad to input [ **61** ], then choose the corresponding defense zone number [**01~99**], then choose [ Home Arm], and then choose whether alarm [**0/1**] button, and finally press [#] to confirm. The main unit will make a long beep and a voice prompt Operating method: [**61**]⇔[**XX**]⇔[**A**]⇔[**#**] XX indicates: [ 01~99 ] is defense zone 1 to defense zone 99 A indicates: [0] Home arm but not alarm [1] Home arm and alarm For example: set defense zone 11 to be Home arm and alarm Operating method: [**61**]⇔[**11**]⇔[**1**]⇔[**#**]

**Functions Settings** 18. Voice Recording In setup state, use keypad to input [701], and then press [#] to confirm. The main unit will emit a beep and the  $[\]$  indicator is on, and after 10 seconds countdown, recording starts: record at 30cm away from the main unit with moderate tone; 10 seconds later, the main unit will make a beep indicating the recording stops and the recorded voice will replay. Operating method: [**701**] ⇒[#] In setup state, use keypad to input [75]; in the operation of arm/ disarm by remote control, select if the siren sounds or not by [0/1] button, and then press [#] to confirm. The main unit will emit a long beep and a voice prompt "setting completed".

Operating method: [**75**]⇔[**A**]⇔[**#**] A indicates: [0] Siren off; [1] Siren on; System default: [0] Siren off For example: set siren on when arm/ disarm Operating method: [**75**]⇔[**1**]⇔[**#**] LCD display:

20. Siren Setting in "Emergency Help" mode In setup state, use keypad to input [76], and then [1/0], finally press [#] to confirm. The main unit will make a long beep and a voice prompt "setting completed" .

Operating method: [**76**]⇔[**A**]⇔[**#**] A indicates: [0]: siren off in "Emergency Help" mode [1]: siren on in "Emergency Help" mode System default: [**0**] siren off

**Functions Settings** [Operation Instructions]

. System status. There are 4 status as following

1). Arm: defense zone 1~99 will alarm when detectors are triggered 2). Home Arm: in arm status, the defense zone which is set as [Home Arm] will alarm when detectors are triggered. 3). Disarm: defense zone  $1\sim99$  will not alarm when detector triggered (except 24 hours defense zone) 4). System setup status: In this status, all defense zones will not alarm when detectors are triggered.

2. Remote Controller Operation Users can use remote controller to set system as Out Arm, Home Arm, Emergency Alarm, Real-time Disarm and etc. 1). Out Arm: Press 🗎 button 2). Disarm: Press 🗖 วutton

3). Home Arm: Press 🗲 button 4). Emergency Alarm: Press button, system will alarm at once. It means, for the safety, while somebody is at home, you need to enable the peripheral door, window, balcony and boundary detectors of the alarm system while prevent from triggering the indoor detectors, which may cause improper warning; then, you shall select Arm at Home, let just part of the detectors work and disable the other parts.

Main Unit Operation: Press [At Home 1] button on keypad Remote Control Operation: Press [4] button on remote controller Functions Settings

It means to guard all around your house while everyone is going out; all the detectors of the host are always working; when the detector is triggered by detecting source (anti-theft, fire prevention, gas leak, etc.), the alarm system will sound the alarm. Press [Out Home📵] button on keypad, system will make a beep per second and totally 100 beeps. The [OUT ARM] indicator will be on

without flashing. It means Out Arm is set successfully. Arm Operation: Press [Out Home 🕒] button, the system will enter arm status 100 seconds later. LCD display: You can also set out arm by SMS remotely. The SMS command is: Remote Control Password (Default: 1234) + [1]

After the setting, the host makes a "Di" sound, ARM LED is on and you will receive a SMS: System armed. It means to stop the alarm when the main unit sounds the alarm or make the alarm system in the state of non-warning. After disarming, even if you trigger the detector, the main unit would not sound alarm (excluding

24-hour defense areas). Use keypad to input system password, then press [#] button. [Out Home] or [At Home] lights will be off. It means disarm setting successful. Remote Control Operation: Press [arrange] button on remote controller Main Unit Operation: input system password + [#]

You can also set disarm by SMS remotely. The SMS command is: Remote Control Password (Default: 1234) + [2]

**Functions Settings** 

After the setting, the host makes "Di" Di" sound, ARM LED is off and you will receive a SMS: System disarmed. Note: If you send arm or disarm SMS by the mobile phone number stored in the system before (refer to "SMS Receiving Number Setting), you will receive two arm/disarm SMS.

6. Answer Alarm Call When the main unit sounds alarm, it will dial the preset numbers. If no one answers the call, the system will call the next user number automatically. The system will call each preset numbers for 3 times in order. If you answer the call, you will hear the pre-record voice. You can set system via your telephone or mobile phone keypad. If you hang-up directly without answering the call, the system will call each

preset number for 3 times circularly. Press [\*]: Read the alarm information. Press [1]: Main unit stops alarming and Arm; it stops calling users. Press [2]: Main unit stops alarming and Disarm; it stops calling users. Press [3]: Siren off and monitors the scene for 30 seconds; for continued monitoring, press [3] again to monitor for another 30 seconds.

Press [4]: Main unit starts a 30-second two-way intercom. It cannot be controlled by the mobile during the time of intercom. 7. Remote Control Dial the number associated to the alarm main unit by phone (mobile phone ), and after one ringing cycle, you can hear a voice prompt "Please enter password" . If the password is right, you will here

"Press 1 to arm, Press 2 to disarm, Press 3 to Monitor, Press 4 to

Intercom" . If the password is wrong, you will hear a prompt voice

"wrong password, please re-enter".

Functions Settings

Press [1]: arm, if finished successfully, you will hear a voice prompt Press [2]: disarm, if finished successfully, you will hear a voice prompt "System disarmed" . Press [3]: monitoring for 30 seconds, to continue monitoring, press [3] again to monitor for another 30 seconds. Press [4]: two-way intercom for 30 seconds. You can't operate the main

unit during this time. 8. Emergency Help Press [Emergency 💿 button on keypad, or [ 🛕 button on remote controller or wireless panic button, the main unit will alarm and make call to the preset user numbers.

9. System Dialing Function In disarm status, you can use the main unit to make any call just like a land-line telephone. Dial telephone number on keypad, press [ <a> ]</a> button, the main unit will make a beep and the [Signal] indicator will be flashing. After the call, press [@] button again, the main unit will be in disarm status.

10. Alarming Record Checking In disarm state, input [\*0#], then the main unit will make a long beep and enters the state of alarm record checking. After displaying the alarm and defense zone number indicator, the LCD screen will display the exact alarming time of this defense zone. Press 2, you can upturn to check the previous alarming record; press 8, downturn to check; and press [\*#]

**Functions Settings** 

For example: the 51st defense zone; the 7th alarming; alarming time: 12:10, August 1st, 2008. LCD display for one second, and then display the alarming

- 12:00 - O75 I You can also check the alarm records by SMS (Max: Latest 9 records). SMS Check Command: Remote Control Password (Default: 1234) + [3] Reply SMS: Eg: Alarm record: NO1 Zone: 05 TIME: 11-06-25 11:37

(It indicates the first record: wireless zone 5 alarm time)..... NO9 Zone: 19 Time: 11-06-25 11:45 (It indicates the first record: wireless zone 19 alarm time) 11. GSM Signal Checking Before installing the main unit, you should check the signal of the installing place in order to ensure the unit can perform well. In setup state, input [81] #, the main unit will make a long beep and display 00 + XX (XX indicate s the intensity of the signal). And the intensity should be within

the range of 07-31; if it's less than 07, you should change place. For example: if the signal intensity is 12, it will display as: Only under Out Arm status, the system has the function of sending SMS alert for power failure/ power recovery. While in Disarm or Home Arm status, it does not. The SMS content:

Power failure: Power charger off

Power recovery: Power charger on

**Technical Parameters** 

NI-HI AAA\*6 DC7.2V

180sec Home Appliance Optional

[ Technical Parameters] [Components list] Input Vo**l**tage Standby Current <55mA Door sensor <450mA Alarming Current User manual Wireless Frequency 315/433MHz, PT2262/EV1527, 4.7M $\Omega$ GSM Frequency 900/ 1800/ 1900MHz

Defense Zone Arm Home Arm Type Alarm Information Siren effective invalid real-time Door alarm effective invalid real-time Hall alarm effective effective real-time Window alarm effective effective real-time Balcony alarm effective effective 24 hours Fire alarm effective effective 24 hours Gas alarm effective effective 24 hours Emergency alarm no Zone 7-99 effective invalid real-time Emergency alarm yes effective invalid real-time Emergency alarm yes

[Care and Maintenance] The alarm system has excellent design and uses advanced technologies. It shall be used with care. The following suggestions are required to maintain your obligations under the warranty terms, and for prolonging the service life of the system. Place the control panel and all parts and accessories out of children's Keep the alarm system dry. Rain, humidity and various fluids or moisture all will corrupt the electronic circuit. Do not use or place the alarm system in dirty locations, otherwise the electronic elements will be damaged. Do no place the system in excessively hot locations. High temperature will shorten the service life of electronic equipment, damage batteries, deform or even melt some plastic parts. Do not place the system in excessively cold locations. Other wise condensation many occur and damage the circuit board of the alarm system. It is recommended that you check and test the alarm system periodically:

1pc Remote contro**ll**er

1pc Power adapter

PIR sensor

Care and Maintenance Check the main unit every three months: Whether it can arm/disarm normally; 2. Whether it can dial the number for alarm normally; 3. Whether it can receive wireless detectors' signal normally; 4. Whether the back - up battery can work normally.

Check the wireless detectors once a month: 1. Trigger wireless detectors to see if system can alarm normally; 2. Check all detectors' batteries to see if it's in low voltage; 3. Check whether wireless detectors can send signal to the main Check the SIM card:

1. Check the use of SIM card, such as network signal, balance, etc. 2. Make sure the PIN code verification of the SIM card is closed. 3. Please keep the password and SIM card number safe, in case that other people remote control the system illegally. Since the alarm system is continuously in operation or standby mode,

the supply adaptor of the control panel shall be connected to a safe

and reliable socket. Do not place the system near your bedroom or office table, because the siren will make high-loudness sound in the case of alarm, which may adversely affect your rest or work. If the alarm system will not be used for a long time, please disconnect the system from the power supply. Please do not disassemble, repair or alter the products without permission, or it may cause accidents and faults.

Care and Maintenance Do not drop this product on the ground or on hard objects, as it may lead to massive impact to cause faults and damages. Without approval and consent of relevant authorities, please do not set "110", "119" or the alarm phone number of police station for this



